

----- rectangular characteristics – phase current
(fullstep / with boost)
both phases with nominal current (bipolar)

..... sinus-/cosinus characteristics – phase current
(without boost)
with peak value = nominal current (bipolar)

e.g. SM 88.2.18M8
with nominal current 8 A/phase bipolar

